



Order stops
 stops at end
 of function
 Cycle stops
 stops at end
 of block.

Stop Mode Normal.

* THESE OUTPUTS ARE INPUT TO THE TIMER DRAWING FIG A21

TO BE READ IN CONJUNCTION WITH 322 A 7191

TITLE
 920B COMPUTER
 MANUAL CONTROLS AND
 STORE HEATER LOGIC

A15