


TOP



REAR VIEW

3-SKT-7 READER LAMPS AND SWITCHES.

3-SKT-6 TAPE READER SIGNAL INPUT AND 10V. DC. SUPPLY.

3-SKT-5 MAINS VOLTAGE TO READER MOTOR. RUNOUT STOP AND TAPE OUT SWITCHES.

3-SKT-4 +28V. SOURCE TO PUNCH COILS. PICK-UP COILS.

3-SKT-3 MAINS VOLTAGE TO TAPE PUNCH.

3-PL-2 INPUTS TO READER TRANSMITTERS. INPUTS TO PUNCH RECEIVERS.

3-PL-1 28V. DC. SUPPLY AND MAINS INPUT TO TAPE PUNCH.

| POS. | DESIGNATION | FUNCTION                               | DRAWING No.        |
|------|-------------|--|--------------------|
| 1    | A-FY.       | +6-0V. DC. 0V.-6-0V. DC. POWER SUPPLY. | 322 D 4917 SHT. 1. |
| 2    | A-AR3.      | PAPER TAPE READER CONTROL 2.           | 322 C 2549         |
| 3    | A-AQ3.      | PAPER TAPE READER CONTROL 1.           | 322 C 5121         |
| 4    | A-AP3.      | PAPER TAPE READER REGISTER.            | 322 C 2481         |
| 5    | A-FX.       | RECEIVERS AND TRANSMITTERS.            | 322 C 4611         |
| 6    | A-A03       | PAPER TAPE PUNCH CONTROL 2.            | 322 C 2482         |
| 7    | A-AN3       | PAPER TAPE PUNCH CONTROL 1.            | 322 C 2650         |
| 8    | A-AM3.      | PAPER TAPE PUNCH REGISTER.             | 322 C 2611         |
| 9    | A-AK3       | PAPER TAPE PUNCH DRIVERS.              | 322 C 2805         |
|      |             | SPARE                                  |                    |
|      |             | SPARE                                  |                    |
|      |             | SPARE                                  |                    |
|      |             |  |                    |

TOP WHEN VIEWED FROM FRONT

PAPER TAPE CONTROLLER  
CONNECTOR AND UNIT LAYOUT

C1