



TITLE  
 AUTO MODE CONNECTIONS AT  
 COMPUTER SKT11 WHEN START  
 ADDRESS PLUG OR PROGRAM  
 LOADING UNIT IS CONNECTED

C14