


RESISTORS	R1	R2	R3	R4-R57 R6 R56	R58-R57	R7	R8	R9	R10	R11	R12-R14 R13 R62	R15-R17 R16 R63	R18-R21 R19 R64 R59 R65 R67 R68	R22-R23 R23	R24-R25 R26	R27	R28	R29-R30 R31 R30	R31	R32	R33	R34	R35	R36																		
CAPACITORS	C1													C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13																		
MISC.	D15-D17 D14-D16	VT1	D18 D27	D19 D28	VT2	VT9 VT17	VT25	D2	D20 D21	D23 D30	VT3	D32 D32	VT10 VT18	D4	VT11 VT19	VT4	VT12 VT20	VT5	VT14 VT22	VT15 VT25	VT6 VT24	T1	T3	VT103- VT104 VT105- VT106	D5 D6	VT107 VT105	D6	D7 D8	T4	D9 D10	C119 C120	C117	C7 C118	C8	C101- C103	C110- C115	C10	C9	C11	D15	VT8	D14

A-HG BOARD PL 322C 5262



FROM  
AUXILIARY  
INVERTER

NOTES  
1. \* INDICATES SELECT-ON-TEST RESISTOR

30 MA.  
RAS SUPPLY.

FROM  
SHUT-  
DOWN  
LOGIC.

D3