# ELLIOTT Global Control Contr

Volume 2: PROGRAMMING INFORMATION

Part 7: MAGNETIC TAPE ROUTINES

Section 6: QMSTAT

### CONTENTS

													Page
Chapter	1: INTRODUCTION 1.1 Function										1		
	1.1												•
	1.2	Form of Distribution	n						• •	• •			1
	1.3	Method of Use						0 0				• •	1
	1.4	Configuration											1
Chapter	2: FUNCTIONS												
	2.1	Check Status Word.											3
	2.2	Exit											3
	2.3	Store Used											3

# Chapter 1: INTRODUCTION

### 1.1 Function

To check the status of a magnetic tape.

# 1.2 Form of Distribution

The routine is distributed on a SIR mnemonic tape, part of the MTBLOCK tape.

### 1.3 Method of Use

The program is assembled and entered as a SIR subroutine.

# 1.4 Configuration

The minimum configuration for running this program is a 903 central processor with 8192 words of store, a magnetic tape controller and at least one magnetic tape handler.

## Chapter 2: FUNCTIONS

2.1 Check Status Word

Enter by: 11 QMSTAT

8 QMSTAT + 1

0 FT

where 0 FT points to the file table.

2.2 Exit

The routine exits with a status word in the A-register. Exit is standard to the second location after entry.

If the appropriate bit is one, the meaning implied is:

Bits 18-3 Undefined.

Bit 2: Handler in Manual, all other bits undefined.

Bit 1: Handler busy, rewinding.

2.3 Store Used

QMSTAT occupies 11 locations.